

601 Desk Lamp Accessory Kit

User Manual

Replacement Shade + Gooseneck Arm + Metal Head + Square Base

Product Model:
601

Kemotronics Industrial Lighting
www.cnclight.com

1. PRODUCT OVERVIEW

Thank you for choosing the 601 Desk Lamp Accessory Kit. This kit contains everything needed to rebuild or repair a classic 601-style gooseneck desk lamp: a plastic lampshade (white or black), a flexible metal gooseneck tube with threaded metal lamp head, and a square metal mounting base. The kit is delivered unassembled; wiring is NOT included. You wire and assemble it yourself, making it ideal for lamp repair and DIY desk lamp projects.

2. TECHNICAL SPECIFICATIONS

Parameter	Value
Model	601
Type	Desk Lamp Accessory Kit
Shade	Plastic, White or Black (per option)
Shade Height	Approx. 120mm
Gooseneck Tube	Metal, OD 12mm, approx. 505mm long
Lamp Head	Metal, threaded connection
Base	Square metal, 40x40mm, 4 holes (25x25mm, 5mm)
Assembled Height	Approx. 640mm
Wiring	Not included
Assembly	Required (DIY)

3. PACKAGE CONTENTS

- 1 x Lamp shade (color per selection)
 - 1 x Gooseneck tube with metal lamp head
 - 1 x Square mounting base
- (Mounting screws may or may not be included depending on batch - contact seller if needed.)

4. INSTALLATION INSTRUCTIONS

- Step 1: Unpack all parts and check them against the package contents list.
- Step 2: Fix the square base onto your desk or workbench with suitable screws through the 4 mounting holes.
- Step 3: Attach the gooseneck tube to the base and tighten the connection.
- Step 4: Fit the lampshade onto the metal lamp head and tighten it securely.
- Step 5: Install a standard bulb of suitable wattage into the lamp head (bulb not included).
- Step 6: Wire the lamp head to your power supply through a switch (follow local electrical codes), then test.

5. WIRING DIAGRAM

NOT APPLICABLE - this is a mechanical parts kit and no wiring is included. The lamp head must be wired by the user to a suitable bulb socket / switch / power cord following local electrical regulations.

6. COLOR STATUS RECOMMENDATIONS

NOT APPLICABLE - this product is not a signal lamp. Shade color (White / Black) is a style option only.

7. MAINTENANCE AND CARE

Clean the shade periodically with a soft, dry cloth.

Do NOT use abrasive cleaners or solvents on the shade.

Check the gooseneck joints and base screws occasionally for tightness.

Keep the threaded lamp head clean and free of corrosion.

Store in a dry place when not in use.

8. SAFETY WARNINGS

- ❑ This kit contains NO wiring. All electrical work must be done by a qualified person following local electrical codes.
- ❑ Always disconnect power before installing bulbs or performing maintenance.
- ❑ Use only bulbs within the wattage rating of your socket assembly. Oversized bulbs cause overheating.
- ❑ Do NOT use the lamp near water, heat sources or flammable materials.
- ❑ Do NOT exceed the gooseneck bending range; excessive force may damage the tube.
- ❑ Keep away from children during assembly - small parts are a choking hazard.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not light	Wiring not connected	Check all wiring connections
	Wrong bulb	Install a working bulb of correct type
	Faulty switch/socket	Test and replace the switch/socket
Light flickers	Loose wiring	Tighten all connections
	Loose bulb	Tighten the bulb in the socket
Shade wobbles	Joints loose	Tighten gooseneck and head joints
Base unstable	Screws not secured	Fix base with suitable screws

10. WARRANTY POLICY

1-year warranty against manufacturing defects in materials and workmanship.

Covers: replacement or repair of defective parts.

Does NOT cover: improper installation, misuse, self-wiring errors, incorrect voltage, normal wear, unauthorized repairs.

11. AFTER-SALES SERVICE

Contact: Jude

Phone: +86-15915305795

Email: sales01@birtechnology.com

Website: www.cnclight.com
